

3 PHYSICAL EXAMINATION & CLASSIFICATION OF FIRED CARTRIDGE CASES	Page 1 of 3
Division of Forensic Science FIREARM/TOOLMARK PROCEDURES MANUAL	Amendment Designator: A
	Effective Date: 19-December-2003
<div data-bbox="331 348 1369 380" data-label="Section-Header"> <h3>3 PHYSICAL EXAMINATION & CLASSIFICATION OF FIRED CARTRIDGE CASES</h3> </div> <div data-bbox="151 411 391 443" data-label="Section-Header"> <h4>3.1 Introduction</h4> </div> <div data-bbox="246 474 1490 562" data-label="Text"> <p>The initial examination of any fired cartridge case evidence will include the completion of a worksheet. These worksheets will include the physical description of the fired cartridge case and will serve as a source to document the condition of the evidence as received and any tests or comparisons performed.</p> </div> <div data-bbox="151 594 496 625" data-label="Section-Header"> <h4>3.2 Safety Considerations</h4> </div> <div data-bbox="246 657 1471 745" data-label="Text"> <p>Examinations performed in the Firearm and Toolmark Section are inherently hazardous. These procedures involve hazardous chemicals, firearms, ammunition, and power tools. All hazardous procedures must be performed in compliance with the DFS Safety Manual.</p> </div> <div data-bbox="151 777 634 808" data-label="Section-Header"> <h4>3.3 Preparation of Cleaning Solutions</h4> </div> <div data-bbox="246 840 1156 871" data-label="Text"> <p>NOTE: ALWAYS ADD ACID TO WATER. NEVER ADD WATER TO ACID.</p> </div> <div data-bbox="246 900 568 932" data-label="Section-Header"> <h5>3.3.1 Acetic Acid Solution</h5> </div> <div data-bbox="344 963 1546 1089" data-label="List-Group"> <ul style="list-style-type: none"> • Prepare a 15% Acetic Acid Solution by combining 150 milliliters of Glacial Acetic Acid to 850 milliliters of distilled water • Store solution in an appropriate, sealed container that is marked with the date and initials of the preparer • Record in the Firearms Quality Record Book </div> <div data-bbox="246 1119 521 1150" data-label="Section-Header"> <h5>3.3.2 Bleach Solution</h5> </div> <div data-bbox="344 1182 1500 1278" data-label="List-Group"> <ul style="list-style-type: none"> • Prepare a Bleach Solution by combining 10 milliliters of bleach to 90 milliliters of distilled water • Store solution in an appropriate, sealed container that is marked with the date and initials of the preparer • Record in the Firearms Quality Record Book </div> <div data-bbox="151 1308 435 1339" data-label="Section-Header"> <h4>3.4 Instrumentation</h4> </div> <div data-bbox="246 1371 557 1530" data-label="List-Group"> <ul style="list-style-type: none"> • Comparison Microscope • Stereo Microscope • Micrometer/Caliper • Ruler • Scale/Balance </div> <div data-bbox="151 1560 763 1591" data-label="Section-Header"> <h4>3.5 Minimum Analytical Standards and Controls</h4> </div> <div data-bbox="246 1623 380 1654" data-label="Text"> <p>Appendix A</p> </div> <div data-bbox="151 1684 501 1715" data-label="Section-Header"> <h4>3.6 Procedure or Analysis</h4> </div> <div data-bbox="246 1747 1490 1806" data-label="Text"> <p>The evidence will be marked in accordance with the Quality Manual. A systematic approach should be used for the physical examination and classification of fired cartridge cases, with recording of findings and observations in notes.</p> </div> <div data-bbox="246 1837 885 1869" data-label="Section-Header"> <h5>3.6.1 General, Visual, Physical, and Trace Examinations</h5> </div>	

3 PHYSICAL EXAMINATION & CLASSIFICATION OF FIRED CARTRIDGE CASES	Page 2 of 3
Division of Forensic Science FIREARM/TOOLMARK PROCEDURES MANUAL	Amendment Designator: A
	Effective Date: 19-December-2003
<p>The initial examination of any cartridge case will include a worksheet. This worksheet will serve as a source to document the condition of the evidence as received. Further information will be added to the worksheet as tests are performed.</p> <p>Examine the cartridge case visually and microscopically for any trace material. Determine if further examination of the material is necessary and consult the appropriate section prior to the removal of the material. Document findings and observations and record in notes.</p> <p>Once the cartridge case has been examined for the presence of pertinent trace evidence material, visual and physical examinations are conducted to determine the following features, to be documented on the worksheet:</p> <ul style="list-style-type: none"> • Any trace material present • Caliber • The possible manufacturer/marketer of the cartridge case • Ignition system – centerfire, rimfire, other • Description of metal used in cartridge case and primer • Description of headstamp • Description of firing pin impression <p>3.6.2 Trace Material Examination</p> <p>Evidence recovered during an investigation may contain trace material transferred from the crime scene. This material may be in the form of blood, tissue, plaster, paint, hairs, fibers, glass, etc. The examiner needs to evaluate the importance of this evidence, and if further examination of the material is necessary, remove and preserve a sample of the material present. Removal of the material may also be necessary to allow the proper examination of the evidence.</p> <ul style="list-style-type: none"> • Remove material being careful not to damage the evidence • Place the removed material into a suitable container/packaging for possible submission to the appropriate section for further examination • Record findings and observations in notes <p>If the trace material IS NOT going to be retained for further examination, proceed with the following:</p> <ul style="list-style-type: none"> • For evidence containing blood, tissue, or other biohazards, soak or sonicate the evidence for at least one (1) minute in a Bleach Solution (refer to 3.2) • Remove loosened material by rinsing with methanol or water • Remove plaster by soaking in a 15% Acetic Acid Solution (refer to 3.2) • Remove paint by soaking in alcohol or acetone • Use a non-abrasive brush to remove loose material • Use Naval Jelly™ or E-zest™ coin cleaner to removed dark stains as needed • Record findings and observations in examiner's notes <p>3.6.3 Caliber Determination</p> <p>Caliber can usually be determined by examination of the headstamp of the cartridge case, and is written as a numerical term that may be depicted with or without a decimal point. If it is not legible on the headstamp, the cartridge case can be compared with laboratory standards, available manufacturer literature, or the computerized FBI Standard Ammunition File.</p>	

3 PHYSICAL EXAMINATION & CLASSIFICATION OF FIRED CARTRIDGE CASES	Page 3 of 3
Division of Forensic Science FIREARM/TOOLMARK PROCEDURES MANUAL	Amendment Designator: A
	Effective Date: 19-December-2003
<div data-bbox="248 348 600 378" data-label="Section-Header"> <p>3.6.4 Determination of Marks</p> </div> <div data-bbox="345 409 1542 472" data-label="Text"> <p>Visual and microscopic examination of the cartridge case may reveal a variety of markings. Types of marks that might be found may be as follows:</p> </div> <div data-bbox="391 501 675 772" data-label="List-Group"> <ul style="list-style-type: none"> Breech face class marks Extractor marks Ejector marks Resizing marks Chamber marks Anvil marks (rimfire only) Magazine marks Ejection port marks Other marks </div> <div data-bbox="345 806 1542 869" data-label="Text"> <p>As appropriate, compare marks on cartridge case with tests from a firearm or with other cartridge cases (see Section 5).</p> </div> <div data-bbox="345 898 1542 961" data-label="Text"> <p>Only the above marks necessary to effect an identification or elimination are required to be documented in the case notes. Additional markings, as determined by the examiner, may also be documented.</p> </div> <div data-bbox="248 991 600 1020" data-label="Section-Header"> <p>3.6.5 Interpretation of Results</p> </div> <div data-bbox="345 1052 1542 1211" data-label="List-Group"> <ul style="list-style-type: none"> • May determine caliber and brand/manufacturer/marketer of cartridge case • May determine if there are suitable markings for identification with a firearm or with other fired components • May determine possible firearms that could have fired cartridge case • May be able to identify the firearm in which it was fired • Record interpretation of results in the notes </div> <div data-bbox="151 1241 527 1274" data-label="Section-Header"> <p>3.7 Appropriate Appendices</p> </div> <div data-bbox="248 1304 631 1333" data-label="Text"> <p>Appendix A - Calibration Standards</p> </div> <div data-bbox="248 1362 535 1394" data-label="Text"> <p>Appendix C - Work Sheets</p> </div> <div data-bbox="151 1423 371 1453" data-label="Section-Header"> <p>3.8 References</p> </div> <div data-bbox="248 1484 1023 1516" data-label="Text"> <p>Association of Firearm and Toolmark Examiners Glossary, 3rd ed. 1994.</p> </div> <div data-bbox="248 1545 1023 1577" data-label="Text"> <p>Association of Firearm and Toolmark Examiners Glossary, 4th ed. 2001.</p> </div> <div data-bbox="248 1606 1234 1638" data-label="Text"> <p>Howe, Walter, J. "Laboratory Work Sheets". <u>AFTE Newsletter</u>. No. 2, August 1969, p. 13.</p> </div> <div data-bbox="248 1667 394 1698" data-label="Text"> <p>www.afte.org</p> </div> <div data-bbox="1482 1793 1542 1822" data-label="Text"> <p>◆ End</p> </div>	